


Auswahlhilfe

# System ITS



## Werkstoffe Erodieren




V 91571 V 91371 V 9237x V 9257x



V 91570 V 91311 V 9231x  
V 9232x V 9258x



V 91381 V 91811 V 9238x



V 91550 V 91552 V 9256x V 9255x



V 91811 V 91311 V 9222x V 94311




V 91411 V 93210 V 93220 V 93225 V 93110 V 93120 V 93160 V 93140 (WCu) V 93240 V 93250 V 93255


## Elektrodenhalter



HER 1112 HER 1412




HER 1472 HER 1672



HER 1442 HER 1642



HER 1122 HER 1422 HER 1622



HER 1185 HER 1680



HER 1130 HER 1132 HER 1134

## Spannzapfen



HER 1805



HER 1805



HER 1805



HER 1812



HER 1812



HER 1810

## Elektrodenbearbeitung



HER 3010



HER 3030



HER 3050



HER 3012



HER 3032




HER 3010

## Allgemeines Zubehör



V 95500 HER 1840 HER 1822



HER 1850/16 HER 1890



HER 1850/16 HER 1890 HER 1822



HER 1850/16 HER 1890 HER 1822



HER 1850/16 HER 1890 HER 1824



HER 1839 HWZ 9000 HWZ 9719

## Mess- und Kontrollelemente




HER 2110 HER 2112 HER 2230/30 HER 2230/40

## Spannzapfen Zubehör




HER 1805






HER 2160 HER 2162









# System 1








## Werkstoffe Erodieren

 V 91571	 V 91371	 V 9237x	 V 9257x
 V 91570	 V 91311	 V 9231x V 9232x	 V 9258x
 V 91381	 V 91811	 V 9238x	
 V 91550	 V 91552	 V 9256x	 V 9255x
 V 91411 V 93210 V 93220 V 93225	 V 93110 V 93120	 V 93160	 V 93140 (WCu) V 93240 V 93250 V 93255






## Elektrodenhalter

 HER 1212		
 HER 1272		
 HER 1242		
 HER 1222	 V 95500	 HER 1212
 HER 1230	 HER 1232	

## Spannzapfen

 HER 1910
 HER 1910
 HER 1912
 HER 1912
 HER 1910






## Elektrodenbearbeitung

 HER 3530
 HER 3532
 HER 3535
 HER 3534
 HER 3530

## Allgemeines Zubehör

 V 95500	 HER 1840	 HER 1922
 HER 1850/16	 HER 1890	
 HER 1850/16	 HER 1890	
 HER 1850/16	 HER 1890	
 HER 1839	 HWZ 9000	 HWZ 9719

## Mess- und Kontrollelemente Spannzapfen Zubehör

 HER 2410	 HER 2120	 HER 2530	 HER 1910	 HER 2160
---	---	---	---	---

Entdecken Sie unser komplettes Sortiment:

[www.meusburger.com/erodierzubehoer](http://www.meusburger.com/erodierzubehoer)